


1/10遥控四驱门桥仿真攀爬车YK41012 说明书

1/10 SCALE RC ROCK CRAWLER 4WD YK41012 INSTRUCTION MANUAL



感谢您购买我们的产品！祝您玩得开心，为了获得最佳产品性能体验，请在使用前务必认真阅读说明书。

Thank you for your purchasing. Before operating this vehicle, please read manual materials thoroughly. This manual contains all the necessary set-up and operating procedures that allow you to unlock the performance.

目录	01
操作说明和注意事项	02~06
爆炸图	07~18
配件表	19~24

Table of Contents	01
Instructions and Precautions	02~06
Explode Diagram	07~18
Parts List	19~24

安全注意事项 SAFETY PRECAUTIONS AND WARNINGS

年龄建议：不适合14岁以下儿童。 这不是玩具。

Age Recommendation: Not for children under 14 years. This is not a toy.

- 1) 严禁在公共场所或拥挤的地方操作模型车, 本产品不允许儿童在没有成人直接监督下使用。
Never operate the model in public places and the street or in populated areas for any reason. This product is not intended for use by children without direct adult supervision.
- 2) 严禁反接电池或拆解电池, 这是危险的, 并可能引起火灾。
Never reverse install the battery or disassemble the battery, which is dangerous and may cause a fire.
- 3) 本产品包含细小且锋利的零件, 请将任何化学品、小零件和电子设备放在儿童接触不到的地方。
This product contains small and sharp parts, keep all chemicals, small parts and anything electrical out of the reach of children .
- 4) 当不使用模型车时, 请先断开电源并把电池从车身移出。此外遥控器电源关闭后, 应取出电池以免漏液。
When not use the vehicle, power OFF the vehicle and then the transmitter. Unplug the battery and remove it from the vehicle. Also remove the transmitter battery to avoid leakage.
- 5) 请不要混用新旧或不同类型电池。
Please do not mix old and new batteries or different types of batteries.
- 6) 不要在遥控器电池电量低的情况下操作车子, 如果电池电量过低, 请更换电池。
Never operate your model with low transmitter batteries. Replace batteries when vehicle batteries are low.
- 7) 在开机状态下, 切勿拆卸遥控器电池。
Never remove the transmitter batteries while the model is powered ON.
- 8) 请根据当地有关规定, 妥善弃置或回收电池。
Dispose of used batteries according to national regulations.
- 9) 充电时, 请从模型车中取出电池, 如果电池变形, 请不要使用。
When charging the battery, please take out the battery from the vehicle. If the battery is deformed, please do not use it.
- 10) 电池应在成人监督下充电, 无人看管时请勿给电池充电。
The battery should be charged under adult supervision, do not charge the battery when unattended.
- 11) 遥控系统有各种不同功能和设置, 初次接触前请确保对所有功能设置完全理解, 未能正确操作可能导致产品损坏。
The radio system has different functions and settings, please read the entire manual to gain a full understanding of functions, failure to operate correctly could result in product malfunction and damage.


产品规格参数 PRODUCT SPECIFICATION:

车长Length:	518mm
车宽Width:	251mm
车高Height :	235mm
轮胎Tire Diameter/Width:	116/42mm
轴距Wheelbase:	315mm
车重 Product Weight:	2. 50KG
电池仓尺寸Battery Box Size:	156*48mm
接近角Approach:	55°
离去角Departure:	52°
转向角度Steeringangle:	40°
离地间隙Ground clearance:	60mm

马达齿 Pinion Gear	低速齿轮比 Low speed Gear Ratio	高速齿轮比 Low speed Gear Ratio
12T	81. 95	35. 20
13T	75. 70	32. 50
14T	70. 30	30. 20
15T	65. 60	28. 20

遥控器和电调功能介绍


TRANSMITTER and ESC FUNCTIONS



- | | | | |
|-----------------------------------|-----------------------------------|-------------------------|---|
| 1) 电源开关
Power Button | 5) 4通正反切换开关
CH4 Reverse Switch | 9) 油门中位微调
TH Trim | 13) 油门/刹车扳手 (2通)
Throttle/Brake Trigger(CH2) |
| 2) 1通正反切换开关
CH1 Reverse Switch | 6) 油门舵量旋钮
EPA for Throttle | 10) 第3通道
Channel 3 | 14) 转向轮 (1通)
Steering Wheel (CH1) |
| 3) 2通正反切换开关
CH2 Reverse Switch | 7) 转向舵量旋钮
EPA for Steering | 11) 第4通道
Channel 4 | 15) 电池仓
Battery Installation |
| 4) 3通正反切换开关
CH3 Reverse Switch | 8) 转向中位微调
ST Trim | 12) 挂绳孔
Lanyard hole | |

遥控器电池安装


INSTALLING THE TRANSMITTER BATTERIES



- 按箭头方向滑动，拆下或者安装发射机电池盖。
Remove the battery cover from the transmitter (Slide cover as shown arrow direction)
- 装4颗电量充足的AA电池，注意电池尺寸正负极如图所示，不要装反。
Install 4 AA batteries with sufficient power as shown. Taking care to align the battery polarity.
- 不要混用新旧或不同类型的电池。更换电池型号不正确，或给非充电电池充电有爆炸危险。
Never use different batteries or mixed old and new batteries. Risk of explosion if battery is replaced by an incorrect type or charging non-rechargeable batteries.
- 定期检查遥控器上电池电量。电池电量不足情况下，不能操作车子，信号会遭受影响，车子可能瞬间失控，导致发生碰撞或伤害。长时间不使用时，请将电池从遥控器内取出。
Check the transmitter battery level regularly. Never operate your model with low transmitter batteries, the radio signal may subject to interference and cause momentary loss of control and collisions or injury. When not in use for a long time, please remove the battery from the transmitter.

电调设置说明

ESC Instructions



- F/B/R: 前进/刹车/后退模式
F/B/R: Forward/Brake/Reverse
F/B: 前进/刹车模式
F/B: Forward/Brake
F/R: 前进/后退模式(攀爬模式)
F/R: Forward/Reverse(Crawler mode)


如图所示，电调跳线帽插入不同的位置，调整电调的模式和电池的类型，每次插好后需关掉电调重启生效。

As the image shown, Jumper locations : to change the ESC mode and Battery(LiPo or NIMH). Kindly note restart the ESC to save the setting


电子设备的连接 ELECTRONICS CONNECTION

出厂前所有电子设备均已连接好
第1通道连接15KG舵机控制转向
第2通道连接电调控制动力马达工作
第4通道连接17G舵机控制高低速换挡
注意电池，马达的连接，黑色负极，红色正极。


Before leaving the factory, all electronic devices are pre-connected:
Channel 1: 15KG servo motor for steering control.
Channel 2: ESC for power motor operation control.
Channel 4: 17G servo motor for high-low speed shifting control.
Note the battery and motor connections, with black indicating negative and red indicating positive.





操作模型车 DRIVING PRECAUTIONS



1. 打开遥控器电源开关，遥控器电源指示灯点亮。
Power ON the transmitter, the battery Indicator lights.
2. 打开电调电源开关，电调指示灯点亮，控制系统进入工作状态。
Turn on ESC Power Switch, the LED Lights, indicating control system enters working status.



操作模型车 DRIVING PRECAUTIONS



用手指向后扣动遥控器扳机，车将向前行驶。
用手指向前推动扳机一次为刹车，松开手指待扳机回到中位后再向前推动则为倒车。

To move the vehicle forward, pull the Throttle trigger .




To reverse the vehicle, push the transmitter trigger one time is brake, pause, then return the trigger to center. Push again is Reverse.

操作模型车


DRIVING PRECAUTIONS

车前轮的运动是随遥控器转向轮的调整而改变的。
遥控器转向轮向左转，车前轮也是左转。
遥控器转向轮向右转，车前轮也是右转。

The front wheel movement is controlled by transmitter steering wheel.
Turn transmitter steering wheel left, the vehicle front wheels turns left.
Turn transmitter steering wheel right, the vehicle front wheels turns right.




转向中位微调
Steering trim




在没有操控转向轮的情况下，车辆前轮应该处于中心位置。
如果前轮偏向左侧，请顺时针转动转向微调旋钮进行微调。
如果前轮偏向右侧，请逆时针转动转向微调旋钮进行微调。

Without turning transmitter steering, the vehicle front wheels should maintain a straight line. If not, adjust ST Trim knob until the vehicle tracks straight. If the front wheel is tilted to the left, fine tuning ST Trim knob clockwise. If the front wheel is tilted to the right, fine tuning ST Trim knob counterclockwise.




转向角度舵量调整旋钮
Steering End Point Adjustment




调整转向角度舵量大小，来适应不同弯角路面的行使需要。
顺时针转动该微调旋钮，可以将转向角度调整到最大。
逆时针转动该微调旋钮，可以将转向角度调整到最小。

Adjust Steering End Point to help adapt to different terrains. Clockwise twist this knob: adjust to the maximum steering angles. Counterclockwise twist this knob: adjust to the minimum steering angles.




油门中位微调
Throttle Trim




在没有操控油门扳机的情况下，车辆应该处于静止状态。
如果车子自行前进，请逆时针转动油门中位微调旋钮进行微调。
如果车子自行后退，请顺时针转动油门中位微调旋钮进行微调。

Without operating throttle trigger, the vehicle should be motionless. If vehicle moves forward, counterclockwise adjust Throttle Trim knob. If vehicle moves backward, clockwise adjust Throttle Trim knob.



油门限速旋钮
Throttle Limit




设定遥控油门限速旋钮控制量大小，逆时针旋转是降低控制量（最低可以降到0%），顺时针旋转是加大控制量（最高值为100%正常油门控制量）。对于初学者而言，可以先尝试调低油门控制量来适应车辆。

Set Throttle Limit knob to limits throttle output.


Counterclockwise Throttle Limit knob to reduce the limit output(minimum 0%)

Clockwise adjust Throttle Limit knob to increase the limit output(maximum 100% is for normal)

Suggest the less experienced select Throttle Limit to reduce speed.



正反切换开关
Reverse switch



如果遥控的操作与车辆动作不一致，请调整此正反切换开关，直至遥控操作和车辆动作一致。

If the operation on transmitter is inconsistent with the vehicle actual performs (forward/backward, left/right) , please adjust this switch to correct.

常见问题及故障处理

Troubleshooting

	故障现象 Problems	故障分析 Causes	故障排除 Solutions
遥控器 Transmitter	电源指示灯不亮 LED does not work.	电池没电或电池安装错误 Weak batteries or batteries are not installed properly.	更换新的电池或检查正负极 Replace with new batteries or install them correctly.
	电源指示灯频率式慢闪 LED flashes slowly.	电池电量不足 Low battery power.	更换新的电池 Replace with new batteries.
	指示灯正常亮起，但是无功能，无法操控车辆 Switch on, normal LED indicate, but no function and cannot operate vehicle.	周围可能有其它正在运行的电子产品导致的遥控频率干扰 Signal interference with other transmitters around you.	重启模型车和遥控器或更换场地 Switch off firstly, and then switch on again or change to other places.
模型车 Car	接通电源后指示灯不亮 Connected, but fail to be switched on.	电池没电或电池过放而损坏，或电路接线破损 The battery pack is flat or damaged. The connectors and wires may break.	更换为已充电的电池，检查电池或线路是否损坏 Charge the battery pack and replace with the new battery pack when needed, check all wires and connectors.
	转向异常或失灵 Connected, but fail to be switched on.	检查是否有杂物阻塞转向结构，或转向部件或舵机已损坏 Steering device is jammed or steering servo is damaged.	检查所有部件，更换损坏的或磨损的部件 Check all the steering parts and or steering servo. Fix or replace with new parts if needed.
	能转向，但无法前进或后退 Steering functions, but the car is not able to go forwards or backwards.	电池电力不足， The battery pack is flat. 传动部件损坏或被杂物阻塞。 Damaged or clogged parts in drive train . 电调功能异常 ESC malfunctions.	更换为已充电电池， Charge the battery pack. 清理与更换部件。 Clean, fix and replace with new parts. 更换电调 Replace with new ESC.
	模型车行驶时噪音大 The car drives noisily.	检查是否有杂物阻塞传动部件，或传动部件损坏或脱落，检查齿轮啮合度，检查并分析差速器齿轮是否已出现扫齿、崩牙等现象。 Check if the drive train is tight or blocked or damaged driving parts, Check the gear mesh and check if the diff. is damaged or not.	及时更换已损坏的齿轮、传动轴、传动接杯或差器 Replace with new gears, diff. driveshafts, outdrive cups in the event that they are damaged. Do not use the car until it has been repaired

维修服务

REPAIR SERVICE:

- 车辆需要经常保养，以保持其性能，特别是活动的零件部位，每次玩车后及时清除上面的尘土杂物，保持车辆清洁和良好的保养。
Periodic maintenance in order to ensure the vehicle best performance, especially the running parts. Remove chassis free of dirt and debris after every driving. Keep your vehicle clean and well maintained.
- 定期检查车上有螺丝的地方，有必要就拧紧加固。
Regularly check the screws on the car and tighten them if necessary.
- 经常检查车上面磨损/弯曲/坏掉的部件，有必要就换掉。
Always check for wear/broken/bent parts, and replace it if necessary.
- 所有的零件都可以作为散件在爆炸图上找到编号，有损坏可以在零售商订购更换。有任何问题，都可以在零售商寻求帮助。
All parts listed on the exploded view. Damages can be ordered at the retailer. If you have any questions, you can ask for help at the retailer.

Differential Gear Assembly





差速器组 前/后



21145
平头2.5×8
FH HEX Screw

21122
BB12×18×4


21123
BB15×21×4



Spindle set 转向臂组 左/右

21120
BB 5×11×4



21121
BB 6×12×4



21138
3×14
OH HEX Screw



Front portal Assembly

前桥组




Front portal Assembly




前桥组



后桥组






后桥组







Shock Absorber Before/Middle/After

避震器 前/后







Front portal assembly linkage shock installation

前桥组拉杆、避震器安装






Rear portal assembly linkage shock installation

后桥组拉杆、避震器安装





Gearbox Assembly

波箱组装





Gearbox Assembly

波箱组装




Gearbox Assembly


波箱组装



波箱组装




车架中段组装




Chassis Assembly

车架中段组装




Chassis Assembly

车架中段组装



Chassis Assembly

车架中段组装




Battery box assembly

电池盒组装


如果使用更小体积电池，可通过安装固定座，来缩小电池仓尺寸，防止电池前后移动而损坏。

Battery compartment can be adjusted by the mount to hold the short size battery in case your battery is damaged due to move back and forth.




Chassis Assembly

车架中段组装




Tires Assembly

轮胎组装




Body Assembly

车壳组装



纵万向轴组装 前/后





前后桥总组装




Tires Assembly

轮胎安装




Body Assembly

车壳组装




配件表 Parts List

21000




前桥管
Front Portal Housing

21001




后桥管
Rear Portal Housing

21002




C座
C Hub set

21003




转向座左/右
Spindle Lefts/Right

21004




后轮轴座
Rear Hub

21005




减速箱
Transmission Gearbox

21006




高低速拨叉
Speed Conversion Paddles

21007




电池盒
Battery Case

21008




避震架
Shock Absorber Mount

21009




止推杆固定座
Panhard Bar Mount

21010




大梁支撑/固定座
Chassis Frame Support/Mount

21012



大梁
Chassis Frame

21013




左右侧板
Left and Right Guard Board

21020




转向伺服臂25T
Steering Servo Horn 25T

21025




手动差速锁配件组
Hand Diff Lock Accessory set

21026




纵纵向轴
Plastic Vertical Universal Shdft

21027




纵纵向轴套
Center Universal Drive shaft Bushing

21028




纵纵向接杯
Center Universal Drive Cup

21029




纵纵向接头
Center Universal Joint Coupler

21031




差速壳
Differential Case

21032




差速齿轮组18T/13T
Differential Gears

21033




从动齿轮34T
34T Gear

21034



差速器
Differential Set


21035



主动齿轮11T
11T Gear


配件表 Parts List

21036




差速锁块
Differential Lock Mounting

21040




门桥齿轮11T/21T
Portal Axle Gears 11T/21T

21041




输出轮轴-前
Front Portal Axle Output Shaft

21042




输出轮轴-后
Rear Portal Axle Output Shaft

21043



横万向传动轴
Horizontal Universal Shaft

21044



后直轴
Rear Straight Axle Shaft

21045




波箱齿轮21T-M1.0 (扁孔)
Gearbox 21T Gear

21046




波箱齿轮21T-M1.0 (圆孔)
Gearbox 21T Gear

21047




波箱齿轮15T-M1.0
Gearbox 15T Gear

21048




波箱齿轮9T-M1.0
Gearbox 9T Gear

21049




波箱齿轮33T/15T-M0.6
Gearbox 33T/15T Gear

21050



波箱齿轮31T-M0.6
Gearbox 31T Gear

21051




马达齿14T-M0.6
14T pinion Gear

21052




高低速换挡锁块
Speed Conversion Lock Block

21053




波箱输出轴
Gearbox Output Shaft

21054




波箱变速轴
Gearbox speed shift shaft

21055




波箱二级减速轴
Gearbox Secondary Reduction Shaft

21056




波箱销子3*28
Pins for Gearbox 3*28

21084




止推杆-90mm
Sway Bar

21087




转向拉杆-109mm
Steering Linkage

21088




伺服拉杆
Servo Linkage

21107




550碳刷马达
Brushed Motor

21110



17G舵机
Servo


21111



15KG舵机
Servo

配件表 Parts List

21112




拉杆球头座组
Ball Linkage Ends

21116




球头5.8-7.4
Hollow Steel Pivot Balls 5.8-7.4

21117




球头6.8-7.4
Hollow Steel Pivot Balls 6.8-7.4

21118




球头6.8-7.9
Hollow Steel Pivot Balls 6.8-7.9

21119




轴承5*10*4
Ball Bearing

21120




轴承5*11*4
Ball Bearing

21121




轴承6*12*4
Ball Bearing

21122




轴承12*18*4
Ball Bearing

21123




轴承15*21*4
Ball Bearing

21124




机米4*4
Headless Screws

21125




机米3*3
Headless Screws

21126




机米3*14
Headless Screws

21127




机米3*20
Headless Screws

21128




M4法兰螺母
Flange Lock Nuts

21129




螺丝轴M4-12.5
Screw Axle

21131




盘头内六角螺丝M2*6
Button Head Screws

21132




盘头内六角螺丝M2.5*8
Button Head Screws

21133




盘头内六角螺丝M2.5*10
Button Head Screws

21134




盘头内六角螺丝M2.5*16
Button Head Screws

21135




盘头内六角螺丝M3*8
Button Head Screws

21136




盘头内六角螺丝M3*10
Button Head Screws

21137




盘头内六角螺丝M3*12
Button Head Screws

21138



盘头内六角螺丝M3*14
Button Head Screws


21139



盘头内六角螺丝M3*16
Button Head Screws


配件表 Parts List

21140




盘头内六角螺丝M3*20
Button Head Screws

21141




盘头内六角螺丝M3*26
Button Head Screws

21142




盘头内六角螺丝M3*28
Button Head Screws

21143




盘头内六角螺丝M3*32
Button Head Screws

21144




平头内六角螺丝M2.5*6
Flat Head Screws

21145




平头内六角螺丝M2.5*8
Flat Head Screws

21146




平头内六角螺丝M3*8
Flat Head Screws

21147




平头内六角螺丝M3*10
Flat Head Screws

21148




平头内六角螺丝M3*12
Flat Head Screws

21149




平头内六角螺丝M3*16
Flat Head Screws

21159




垫片8*5.1*0.2
Shims

21160




垫片8*3.1*0.5
Shims

21162




4.0E扣
E Clip

21163




2*10销子
Pins

21164




2*11销子
Pins

21166




盘头内六角螺丝M3*30
Button Head Screws

21230




轮框
Gray Rims

21231




轮胎皮/海绵
Tires/Foams

21232




轮胎组
Wheels

21233




遥控/接收机
Transmitter/Receiver

21234




电调60A
ESC 60A

21240



高低速伺服臂组
High-Low Speed Servo Horn

21244



避震器组
Shock Set Complete


21245



避震盖
shock cap


配件表 Parts List

21246




避震球头座
Shock absorber ball head seat

21247



避震弹簧下座
Shock Rod End and Spring Cups

21248



避震活塞
Shock Piston

21249




避震筒
shock body

21250




避震轴
Shock Shaft Set

21251




避震X圈
Shock X-Ring

21252




避震弹簧
Shock Spring Set

21253




六角轮座
Wheel Hex

13183




盘头十字自攻牙螺丝ST2.5*6
Button head Self-tapping screws

13185




盘头十字自攻牙螺丝ST3*8
Button head Self-tapping screws

21260




车壳安装配件
clips, body post

21261




防撞架
Bumper

21262




车壳配件组
Body accessories

21263




车壳柱
body post

21264




上拉杆-68mm
Camber Link

21265




下拉杆-81mm
Linkage upper

21266




车壳 (透明)
Body (Clear)

21267 (酒红色)
21268 (灰色)
21269 (蓝色)




车壳 (丝印)
Body (Screened)

21270 (酒红色)
21271 (灰色)
21272 (蓝色)



车壳组
Body set



Website: www.yikong.racing