

PRB07003

RagazzaTM

1-METER READY-TO-RUN SAILBOAT


PROBOATTM
ProBoatModels.com

**Owners Manual
Bedienungsanleitung
Manuel de l'utilisateur
Manuale dell'utente**



NOTICE

All instructions, warranties and other collateral documents are subject to change at the sole discretion of Horizon Hobby, LLC. For up-to-date product literature, visit <http://www.horizonhobby.com> and click on the support tab for this product.

Meaning of Special Language

The following terms are used throughout the product literature to indicate various levels of potential harm when operating this product:

NOTICE: Procedures, which if not properly followed, create a possibility of physical property damage AND little or no possibility of injury.

CAUTION: Procedures, which if not properly followed, create the probability of physical property damage AND a possibility of serious injury.

WARNING: Procedures, which if not properly followed, create the probability of property damage, collateral damage, and serious injury OR create a high probability of superficial injury.



WARNING: Read the ENTIRE instruction manual to become familiar with the features of the product before operating. Failure to operate the product correctly can result in damage to the product, personal property and cause serious injury.

This is a sophisticated hobby product and NOT a toy. It must be operated with caution and common sense and requires some basic mechanical ability. Failure to operate this Product in a safe and responsible manner could result in injury or damage to the product or other property. This product is not intended for use by children without direct adult supervision. Do not use with incompatible components or alter this product in any way outside of the instructions provided by Horizon Hobby, LLC. This manual contains instructions for safety, operation and maintenance. It is essential to read and follow all the instructions and warnings in the manual, prior to assembly, setup or use, in order to operate correctly and avoid damage or serious injury.

Age Recommendation: Not for children under 14 years. This is not a toy.

Safety Precautions and Warnings

As the user of this product, you are solely responsible for operating in a manner that does not endanger yourself and others or result in damage to the product or the property of others.

- When handling and/or transporting your boat, always pick up the boat from the front, keeping all moving parts pointed away from you.
- Always keep a safe distance in all directions around your model to avoid collisions or injury. This model is controlled by a radio signal subject to interference from many sources outside your control. Interference can cause momentary loss of control.

- Always operate your model in open spaces away from full-size vehicles, traffic and people.
- Always carefully follow the directions and warnings for this and any optional support equipment (chargers, rechargeable battery packs, etc.).
- Always keep all chemicals, small parts and anything electrical out of the reach of children.
- Always avoid water exposure to all equipment not specifically designed and protected for this purpose. Moisture causes damage to unprotected electronics.
- Never place any portion of the model in your mouth as it could cause serious injury or even death.
- Never operate your model with low transmitter batteries.

Water-Resistant Boat with Waterproof Electronics

Your new Horizon Hobby boat has been designed and built with a combination of waterproof and water-resistant components to allow you to operate the product in calm, fresh water conditions.

While the entire boat is highly water-resistant, it is not completely waterproof and your boat should NOT be treated like a submarine. The various electronic components used in the boat, such as the Electronic Speed Control (ESC), servo(s) and receiver are waterproof, however, most of the mechanical components are water-resistant and require additional maintenance after use.

Metal parts, including the bearings, pins, screws and nuts, propeller, rudder, rudder mounts, prop struts, as well as the contacts in the electrical cables, will be susceptible to corrosion if additional maintenance is not performed after running in wet conditions. To maximize the long-term performance of your boat and to keep the warranty intact, the procedures described in the "Wet Conditions Maintenance" section below must be performed regularly.



CAUTION: Failure to exercise caution while using this product and complying with the following precautions could result in product malfunction and/or void the warranty.

General Precautions

- Read the **WET CONDITIONS MAINTENANCE** procedures and make sure that you have all the tools you will need to properly maintain your boat.
- Not all batteries can be used in wet conditions. Consult the battery manufacturer before use. Take caution when using Li-Po batteries in wet conditions.
- Most transmitters are not water-resistant. Consult your transmitter's manual or the manufacturer before operation.
- Never operate your transmitter or boat when lightning is present.
- Salt water is very conductive and highly corrosive. If you choose to run your boat in salt water, immediately rinse the boat in fresh water after each use. Operating your boat in salt water is at the sole discretion of the modeler.
- Even minimal water contact can reduce the life of your motor if it has not been certified as water-resistant or waterproof. If the motor becomes excessively wet, apply very light throttle until the water is mostly removed from the motor. Running a wet motor at high speeds may rapidly damage the motor.
- Driving in wet conditions can reduce the life of the motor. The additional resistance of operating in water causes excess strain.

Wet Conditions Maintenance

- Drain any water that has collected in the hull by removing the drain plug or canopy and tilting the boat in the appropriate direction to drain the water.

CAUTION: Always keep hands, fingers, tools and any loose or hanging objects away from rotating parts.

- Remove the battery pack(s) and disconnect the ESC and motor. Dry the contacts. If you have an air compressor or a can of compressed air, blow out any water that may be inside the recessed connector housings.

NOTICE: Never use a pressure washer to clean your boat.

- Use an air compressor or a can of compressed air to dry the boat and help remove any water that may have gotten into small crevices or corners.
- Spray the bearings, fasteners and other metal parts with a water-displacing light oil or lubricant. Do not spray the motor.
- Let the boat air dry before you store it. Water (and oil) may continue to drip for a few hours.

Recommended Tools and Materials

- Paper towel
- Clear tape (DYNM0102)
- Pro Boat® Marine Grease and Gun (PRB0100)
- Medium or Thin CA (cyanoacrylate adhesive) or epoxy adhesive
- 2.5mm ball type hex wrench
- 7mm nut driver
- Small flat blade screw driver
- Small Phillips screw driver
- Small needle nose pliers


Product Inspection

Carefully remove the boat and radio transmitter from the box. Inspect the boat for damage. If your product is damaged, please contact the hobby shop where you purchased your boat.

Register your boat online at www.proboatmodels.com.

Table of Contents

Water-Resistant Boat with Waterproof Electronics	2
General Precautions	2
Wet Conditions Maintenance	3
Recommended Tools and Materials	3
Product Inspection	3
Specifications	3
Transmitter Controls	4
Transmitter Battery Installation	4
Binding	4
Failsafe	5
Boat Assembly	5
Mast and Sail Assembly	6
Lines and Winch Operation	7
Boating Tips	7
Getting Started	8
Control Direction Test	8
Adjusting Sails	9
Trimming	9
Control Centering	9
Centering Controls after Voyages	9
When You Are Finished	9
Maintenance and Repair	10
Troubleshooting Guide	10
Limited Warranty	11
Warranty and Service Contact Information	12
FCC Information	12
IC Information	12
Compliance Information for the European Union	13
Instructions for Disposal of WEEE	13
Replacement Parts	47
Optional Parts	47



Specifications

Length	39 in (1.0 m)
Front Beam (width)	14 in (360mm)
Back Beam (width)	14 in (355mm)
Mast Height	61 in (1.55 m)
Total Height	90 in (2.3 m)
Transmitter	2.4GHz 2-stick
Batteries	4 AA batteries (included) to operate the transmitter. 4 AA batteries (included) to operate the receiver.
Receiver	2.4GHz
Hull Material	Fiberglass
Sail Material	Rip-stop nylon
Sail Area (Main)	279 in ² (0.18 m ²)
Sail Area (Jib)	372 in ² (0.24 m ²)
Sail Area (Overall)	651 in ² (0.42 m ²)

Transmitter Controls

Antenna

The transmitter antenna bends at the hinge (A) and only bends to the left side of the transmitter. The antenna cannot point to the right or back of the transmitter. Turn antenna tip to point away from the model and ground. Signals transmit strongest from the antenna shaft, not the tip.



WARNING: Do not pick up the transmitter by the antenna. Do not alter or put weight on the antenna. Damage to antenna parts can decrease transmitter signal strength, which can result in loss of model control, injury or property damage.

Winch Rate

Adjust the responsiveness to the control stick.

Winch Control

Move the Winch Control UP on the transmitter to release the control lines. Move the Winch Control DOWN to pull in the control lines.

Winch Trim

Adjust the center point for winch operation in the transmitter.

LEDs

Transmitter battery level indicators: Green (good) or red (replace).

Steering Rate

Adjust the responsiveness to the control stick.

Rudder Control

Move the Rudder Control RIGHT to move the rudder right. Move the Rudder Control LEFT to move the rudder left.

Power Switch

Power on or off the transmitter.

Rudder Trim

Steering trim is adjusted until the boat tracks straight.

Reverse Switch


Allows you to change the direction of the winch and rudder controls (Ensure proper function with a radio system test).

Transmitter Battery Installation

This transmitter operates on 4 AA batteries.

1. Remove the battery cover from the transmitter.
2. Install the batteries as shown.
3. Install the battery cover.

IMPORTANT: Remove the transmitter batteries after use.



CAUTION: If using rechargeable batteries, charge only rechargeable batteries. Charging non-rechargeable batteries may cause the batteries to burst, resulting in injury to persons and/or damage to property.

Binding


Binding is the process of programming the receiver to recognize the GUID (Globally Unique Identifier) code of a single specific transmitter. The included transmitter and receiver are bound at the factory. If you need to rebind, follow the instructions below.

1. Power off the transmitter and boat switch.
2. Connect a fully charged battery pack to the boat.
3. Power on the boat switch. The RED LED on the receiver flashes.
4. Press the bind button (A) on the receiver. The RED LED on the receiver flashes.

5. Power on the transmitter.
6. The RED LED on the receiver turns solid when the radio system is bound.

You must rebind when binding the receiver to a different transmitter.

NOTICE: Do not attempt to bind the transmitter and receiver if there are other compatible transmitters in bind mode within 400 feet. Doing so may result in unexpected binding.



Failsafe

In the unlikely event that the radio link is lost during use, the receiver will drive the servos to their pre-programmed failsafe positions (normally sails out and straight steering).

If the receiver is powered on before powering on the transmitter, the receiver will enter **FAILSAFE** mode. When the transmitter is powered on, normal control is resumed. Failsafe servo positions are set during binding.

Boat Assembly


Carefully remove the hull, parts and sail tube from the boxes. Fasteners are in bags **(A)**, **(B)**, and **(C)**. Open the sail tube, then remove and unroll the sails.

1. Align and install the weight on the keel using a washer, lock nut (**Bag C**) and a 7mm nut driver.
2. Remove the hatch from the hull. Insert the keel into the hull using a washer, lock nut (**Bag C**) and a 7mm nut driver.
3. Connect the linkages in the outermost holes of the rudder arm (**Bag C**) as shown.

Tip: Apply a thin coat of Marine Grease (PRB0101 or PRB0100) to the rudder post.

4. Install the rudder post in the bottom of the hull, then install the rudder arm on the post, tightening the hex head screw on the flat spot on the post using a 2.5mm hex wrench.
5. Install 4 AA batteries in the battery holder, then connect the holder to the switch connector and install the battery holder in the hull socket.
6. Replace the hatch.

Tip: We recommend applying tape (DYNM0102, sold separately) over the hatch and hull to keep out water.















Mast and Sail Assembly


1. Slide the mast sections together on the wood block and secure the mast using 2 screws (**Bag C**).
2. Install the two spreaders on the right and left sides of the mast using a screw, nut (**Bag B**), Phillips screwdriver and 4mm nut driver.
3. Install the rear boom on the mast using 1 screw (**Bag A**).
4. Loosely install the rear mast line (**Bag A**) on the mast crane using a crimp collar. Crimp the collar only after installing the mast on the hull.
5. Slide the main sail cord through the mast channel down to the boom.
6. Install the mast crane on the mast.
7. Secure 3 corners of the main sail to the mast and boom as shown. Loosen the outermost fitting screw, when needed.
8. Install the left and right mast lines on the mast through each spreader's outermost hole, the mast hooks and the crimp collars.
9. Assemble the turnbuckles using the mast line screws, nuts and barrels (**Bags A and B**).
10. Insert the respective mast hooks in the holes in each side of the mast.

Tip: Where needed, close the circular loop of a mast hook using pliers.

11. Connect the rear (**C**), right (**B**), and left (**B**) mast line turnbuckles to the respectively marked fittings on the hull.
12. Install the bottom of the mast in the hole in the hull.




13. To connect the front boom to the hull, lightly mark the location of the front fitting on the boom. Remove the nuts and bolts from the front fitting and insert the upper ring of the front boom swivel. Carefully install and tighten the nuts and bolts in the fitting to secure the fitting on the boom at the previously marked location.
14. Loosen the lines on the front sail and install the mast hook in the front of the mast.
15. Install the respective winch lines on the fittings of the front and rear booms as shown. Keep the winch lines loose on the booms until you operate the winch servo.
16. Adjust the mast lines (with sufficient tension so the turnbuckles can adjust mast angle in the hull) and crimp the collars on the mast lines using pliers. A collar can only be crimped once.
17. Adjust the turnbuckles on the mast lines so the mast is centered and perpendicular to the hull. Loosen a turnbuckle nut from against the barrel, turn the barrel on the screw threads as needed, then tighten the nut to prevent turning. Wrenches or pliers may be required.



Lines and Winch Operation

Before the first voyage, or in the event of an accident, closely inspect the winch lines (**A**) and ensure they move freely to and from the winch. Always replace worn winch lines and repair the winch so it responds correctly to the transmitter.



Boating Tips

Consult local laws and ordinances before choosing a location to pilot your boat.

When running your boat for the first time, we recommend calm wind and water conditions so that you can learn how the boat responds to your control.

NOTICE: Running the boat in salt water could cause some parts to corrode. If you run the boat in salt water, rinse it thoroughly in fresh water after each use.

NOTICE: Because of its corrosive effects, running RC boats in saltwater is at the discretion of the modeler.

- Carefully place the boat in the water.
 - Operate the boat at slow speeds near the shoreline. Avoid vegetation in the water so the keel and rudder are not blocked. However, if these parts are blocked, remove the boat from the water and remove the debris before continuing operation.
 - Always keep your boat in sight while it is in the water.
 - Once you are comfortable operating the boat at slow speeds, it is safe to operate the boat farther from the shore at higher speeds.
 - Bring the boat back to the shore when you notice the boat starting to become less responsive to the transmitter.
- Use care to avoid boating in areas where there are numerous people (such as swimming or fishing areas or park waterways).
- Avoid boating near:
- other watercraft
 - stationary objects
 - waves, wakes and other rapidly moving water
 - wildlife
 - floating debris
 - overhanging trees
- Operate your boat in water deeper than 22 inches (56 cm).
Crash damage is not covered under warranty.


CAUTION: Never operate your boat in extreme temperatures or turbulent water.

CAUTION: Never attempt to retrieve a downed boat by swimming. If you need to retrieve your boat from the water, use fishing equipment or another boat.

NOTICE: Do not turn off the transmitter first or the receiver may pick up stray signals and run out of control.

Getting Started


1. Power on the transmitter.
2. Connect the battery.
3. Power on the switch harness mounted under the deck hatch.
4. Perform a **CONTROL DIRECTION TEST** with the transmitter.
5. Launch the boat into the water and start sailing.
 - ☐ Install fully charged batteries in your boat and transmitter.
 - ☐ Make sure the boat is bound to the transmitter (otherwise, bind the boat to the transmitter using the included **BINDING** instructions).
 - ☐ Make sure all linkages move freely on the boat.
 - ☐ Adjust the steering rate on your transmitter as desired.
 - ☐ Find a safe and open area of operation.
 - ☐ Plan a safe route for the water and wind conditions.



Control Direction Test

Perform a **CONTROL DIRECTION TEST** to see how quickly your sailboat responds to transmitter controls. In gusty wind conditions, knowing how fast your sailboat responds can make the difference between easy sailing and sinking your boat.

Ensure your boat and transmitter are bound before performing these tests (see **Binding**). Move the controls on the transmitter to ensure the rudder and sails move correctly and in the proper direction. Ensure the rudder moves freely and that the winch servo takes in and releases control lines appropriately.



Move the Winch Control (A) up on the transmitter. The winch in the boat will release control lines, so use one hand to move the sails to the right or left. Move the stick down on the transmitter. The winch will pull in control lines.


Adjust the center point for winch operation in the transmitter (B).

Use the Winch (CH 1) reversing switch on your transmitter if you need to reverse the direction the winch pulls in or releases control lines.

Move the Rudder Control (C) on the transmitter to the right. The rear edge of the rudder should move to the right. Move the stick on the transmitter to the left. The rear edge of the rudder should move to the left.

Steering trim is adjusted until the vehicle tracks straight (D).

Use the CH 2 (steering) reversing switch if the direction is reversed.



Adjusting Sails

After you have centered the sails and the rudder, adjust the sails for optimum fun and safe sailing. Briefly sail the boat to see how the sails need to be trimmed.

Loosen or tighten a line at the cleat by coiling the line around the cleat.

Adjust as desired, but always ensure you do not tighten the line too much and damage your boat.

Adjust the winch lines so the lines are JUST taut when the sails are retracted and the sails do not pass a 60 degree angle to the hull when the sails are extended. Extending the sails past 60 degrees may imbalance the boat, resulting in loss of control.

Contact your local hobby store for information about local model boating clubs or visit www.sailing.org for information about International One Meter (IOM) racing. This model conforms to general requirements for the IOM class; however, consult your local authorities for current regulations.

Trimming

Control Centering

Before the first voyage, or in the event of an accident, make sure the rudder and sails are centered.

1. Make sure the sails and rudder are centered (neutral) when the transmitter controls and trims are centered.
2. When needed, manually adjust the length of the control line between the winch in the boat and the fitting on each sail boom. Always adjust the length of the line at the boom, not on the winch inside the boat.

Centering Controls after Voyages

1. If the model requires excessive transmitter trim (8 or more clicks of trim per channel), return the transmitter trim to zero and adjust the winch lines on the booms manually so the rudder and sails are in the correctly trimmed positions.
2. Ensure the main boom and front sail boom are in line with each other.


When You Are Finished

1. Power off the switch.
2. Disconnect the battery.
3. Power off the transmitter.
4. Remove the battery from the boat.
5. Loosen all lines.
 - ☐ Always power off the receiver before powering off the transmitter to maintain control of the boat and to retain transmitter binding.
 - ☐ Fully dry the inside and outside of the boat. Remove the hatch before storing your boat.
 - ☐ Repair any damage or wear to the boat.
 - ☐ Make note of lessons learned from the trimming of your boat, including water and wind conditions.
 - ☐ Always store the boat open (without the hatch sealed) or moisture may allow mold and mildew to grow in the boat.

NOTICE: When you are finished boating, never leave the boat in direct sunlight or in a hot, enclosed area such as a car. Doing so can damage the boat.

TIP: For transport:


- Untie the winch line from the rear boom
- Detach the 3 turnbuckle hooks from the hull fittings
- Remove the mast from the hull
- Remove the mast hook from the front of the mast



Maintenance and Repair

When parts are not repairable, see the **Replacement Parts List** to order by item number. Refer to the list at the end of this manual for all replacement and optional parts.

Apply CA (cyanoacrylate adhesive) to the end of a line to prevent fraying.



Troubleshooting Guide

Problem	Possible Cause	Solution
Boat does not respond to the transmitter	Boat receiver is not bound to the transmitter	Bind the receiver to the transmitter
	Low or no power	Replace/recharge batteries Ensure connections are secure and powered on
	Fouled or broken sails, lines or servo	Straighten, tighten or replace damaged parts
Boat moves too fast or too slow for the wind and water conditions	Rigging may be worn	Repair or replace damaged parts
	Sails may be adjusted too tight	Loosen or adjust the sail rigging for wind and water conditions
	Steering rate incorrect on the transmitter for the wind and water conditions	Adjust the steering rate
	Vegetation or other obstacles block the rudder, keel or sails	Remove vegetation or obstacles from rudder, keel or sails
Boat tends to turn one direction	Sails are not centered	Center and adjust the sails and control lines for the wind and water conditions
	Rudder is not centered	Adjust or repair rudder, connectors or servo
Boat tends to drift	Sails are not centered	Center and adjust the sails and control lines for the wind and water conditions
	The rigging is worn or broken	Repair or replace damaged rigging
	Rudder is not centered	Adjust or repair rudder, connectors or servo
Boat tends to dive in the water or takes on water	Sails are rigged too high or low on the mast	Adjust the tightness of the rigging at the top corner and bottom of each sail
	Sails are tied too tight	Loosen lines
	The boat hull is not completely closed	Dry out the boat and ensure the hatch is fully closed on the hull before returning the boat to the water
Winch does not respond to transmitter, while rudder does	Winch servo is disconnected	Connect servo to receiver
	Winch, servo, line or other parts are blocked or damaged	Repair or replace parts
	Servo travel is too low	Adjust travel
	Trim is incorrect	Adjust winch line or transmitter trim
Boat will not BIND (during binding) to transmitter	Transmitter is too near boat during binding process	Move powered transmitter a few feet from boat, disconnect and reconnect battery to boat
	Boat or transmitter is too close to large metal object	Move boat or transmitter away from large metal object
	Bind button on the receiver was not pressed	Press and hold the bind button on the receiver
	Low or no power	Replace/recharge batteries Ensure connections are secure and powered on
Boat will not connect (after binding) to transmitter	Transmitter is too near boat during connecting process	Move powered transmitter a few feet from boat, disconnect and reconnect battery to boat
	Boat or transmitter is too close to large metal object	Move boat or transmitter away from large metal object
	Boat battery/Transmitter battery charge is too low	Replace/recharge batteries
	Transmitter may have been bound to a different model	Bind boat to transmitter
Controls reversed	Transmitter settings are reversed	Perform the Control Direction Test and adjust controls on transmitter appropriately

LIMITED WARRANTY

What This Warranty Covers

Horizon Hobby, LLC, (Horizon) warrants to the original purchaser that the product purchased (the "Product") will be free from defects in materials and workmanship at the date of purchase.

What is Not Covered

This warranty is not transferable and does not cover (i) cosmetic damage, (ii) damage due to acts of God, accident, misuse, abuse, negligence, commercial use, or due to improper use, installation, operation or maintenance, (iii) modification of or to any part of the Product, (iv) attempted service by anyone other than a Horizon Hobby authorized service center, (v) Product not purchased from an authorized Horizon dealer, (vi) Product not compliant with applicable technical regulations, (vii) use that violates any applicable laws, rules, or regulations.

OTHER THAN THE EXPRESS WARRANTY ABOVE, HORIZON MAKES NO OTHER WARRANTY OR REPRESENTATION, AND HEREBY DISCLAIMS ANY AND ALL IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE PURCHASER ACKNOWLEDGES THAT THEY ALONE HAVE DETERMINED THAT THE PRODUCT WILL SUITABLY MEET THE REQUIREMENTS OF THE PURCHASER'S INTENDED USE.

Purchaser's Remedy

Horizon's sole obligation and purchaser's sole and exclusive remedy shall be that Horizon will, at its option, either (i) service, or (ii) replace, any Product determined by Horizon to be defective. Horizon reserves the right to inspect any and all Product(s) involved in a warranty claim. Service or replacement decisions are at the sole discretion of Horizon. Proof of purchase is required for all warranty claims. SERVICE OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE PURCHASER'S SOLE AND EXCLUSIVE REMEDY.

Limitation of Liability

HORIZON SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY, REGARDLESS OF WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, TORT, NEGLIGENCE, STRICT LIABILITY OR ANY OTHER THEORY OF LIABILITY, EVEN IF HORIZON HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Further, in no event shall the liability of Horizon exceed the individual price of the Product on which liability is asserted. As Horizon has no control over use, setup, final assembly, modification or misuse, no liability shall be assumed nor accepted for any resulting damage or injury. By the act of use, setup or assembly, the user accepts all resulting liability. If you as the purchaser or user are not prepared to accept the liability associated with the use of the Product, purchaser is advised to return the Product immediately in new and unused condition to the place of purchase.

Law

These terms are governed by Illinois law (without regard to conflict of law principals). This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Horizon reserves the right to change or modify this warranty at any time without notice.

WARRANTY SERVICES

Questions, Assistance, and Services

Your local hobby store and/or place of purchase cannot provide warranty support or service. Once assembly, setup or use of the Product has been started, you must contact your local distributor or Horizon directly. This will enable Horizon to better answer your questions and service you in the event that you may need any assistance. For questions or assistance,

please visit our website at www.horizonhobby.com, submit a Product Support Inquiry, or call the toll free telephone number referenced in the Warranty and Service Contact Information section to speak with a Product Support representative.

Inspection or Services

If this Product needs to be inspected or serviced and is compliant in the country you live and use the Product in, please use the Horizon Online Service Request submission process found on our website or call Horizon to obtain a Return Merchandise Authorization (RMA) number. Pack the Product securely using a shipping carton. Please note that original boxes may be included, but are not designed to withstand the rigors of shipping without additional protection. Ship via a carrier that provides tracking and insurance for lost or damaged parcels, as Horizon is not responsible for merchandise until it arrives and is accepted at our facility. An Online Service Request is available at http://www.horizonhobby.com/content/_service-center_render-service-center. If you do not have internet access, please contact Horizon Product Support to obtain a RMA number along with instructions for submitting your product for service. When calling Horizon, you will be asked to provide your complete name, street address, email address and phone number where you can be reached during business hours. When sending product into Horizon, please include your RMA number, a list of the included items, and a brief summary of the problem. A copy of your original sales receipt must be included for warranty consideration. Be sure your name, address, and RMA number are clearly written on the outside of the shipping carton.

NOTICE: Do not ship LiPo batteries to Horizon. If you have any issue with a LiPo battery, please contact the appropriate Horizon Product Support office.

Warranty Requirements

For Warranty consideration, you must include your original sales receipt verifying the proof-of-purchase date. Provided warranty conditions have been met, your Product will be serviced or replaced free of charge. Service or replacement decisions are at the sole discretion of Horizon.

Non-Warranty Service

Should your service not be covered by warranty, service will be completed and payment will be required without notification or estimate of the expense unless the expense exceeds 50% of the retail purchase cost. By submitting the item for service you are agreeing to payment of the service without notification. Service estimates are available upon request. You must include this request with your item submitted for service. Non-warranty service estimates will be billed a minimum of ½ hour of labor. In addition you will be billed for return freight. Horizon accepts money orders and cashier's checks, as well as Visa, MasterCard, American Express, and Discover cards. By submitting any item to Horizon for service, you are agreeing to Horizon's Terms and Conditions found on our website http://www.horizonhobby.com/content/_service-center_render-service-center.

ATTENTION: Horizon service is limited to Product compliant in the country of use and ownership. If received, a non-compliant Product will not be serviced. Further, the sender will be responsible for arranging return shipment of the un-serviced Product, through a carrier of the sender's choice and at the sender's expense. Horizon will hold non-compliant Product for a period of 60 days from notification, after which it will be


WARRANTY AND SERVICE CONTACT INFORMATION

Country of Purchase	Horizon Hobby	Contact Information	Address
United States of America	Horizon Service Center (Repairs and Repair Requests)	servicecenter.horizonhobby.com/ RequestForm/	4105 Fieldstone Rd Champaign, Illinois, 61822 USA
	Horizon Product Support (Product Technical Assistance)	www.quickbase.com/db/ bghj7ey8c?a= GenNewRecord 888-959-2306	
	Sales	sales@horizonhobby.com 888-959-2306	
United Kingdom	Service/Parts/Sales: Horizon Hobby Limited	sales@horizonhobby.co.uk +44 (0) 1279 641 097	Units 1–4, Ployters Rd, Staple Tye Harlow, Essex, CM18 7NS, United Kingdom
Germany	Horizon Technischer Service Sales: Horizon Hobby GmbH	service@horizonhobby.de +49 (0) 4121 2655 100	Christian-Junge-Straße 1 25337 Elmshorn, Germany
France	Service/Parts/Sales: Horizon Hobby SAS	infofrance@horizonhobby.com +33 (0) 1 60 18 34 90	11 Rue Georges Charpak 77127 Lieusaint, France
China	Service/Parts/Sales: Horizon Hobby — China	info@horizonhobby.com.cn +86 (021) 5180 9868	Room 506, No. 97 Changshou Rd. Shanghai, China 200060

Antenna Separation Distance

When operating your Spektrum transmitter, please be sure to maintain a separation distance of at least 5 cm between your body (excluding fingers, hands, wrists, ankles and feet) and the antenna to meet RF exposure safety requirements as determined by FCC regulations.

The following illustrations show the approximate 5 cm RF exposure area and typical hand placement when operating your Spektrum transmitter.



FCC Information

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.



CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This product contains a radio transmitter with wireless technology which has been tested and found to be compliant with the applicable regulations governing a radio transmitter in the 2.400GHz to 2.4835GHz frequency range.

IC Information

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

 **EU Compliance Statement:** Horizon Hobby, LLC hereby declares that this product is in compliance with the essential requirements and other relevant provisions of the R&TTE, EMC Directive, and LVD Directive.

A copy of the EU Declaration of Conformity is available online at: <http://www.horizonhobby.com/content/support-render-compliance>.



Instructions for Disposal of WEEE by Users in the European Union

This product must not be disposed of with other waste. Instead, it is the user's responsibility to dispose of their waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or where you purchased the product.

47053 Created: 05/2015

©2015 Horizon Hobby, LLC

Pro Boat, the Pro Boat logo, Ragazza, Dynamite, and the Horizon Hobby logo are trademarks or registered trademarks of Horizon Hobby, LLC

The Spektrum trademark is used with permission of Bachmann Industries, Inc. Patents pending.

PRB07003