




Required Tools:

- 1.5 Hex Driver
- 2.0 Hex Driver
- Shock Pliers
- Pliers
- Thread-locker 



VIDEO MANUAL
ON YOUTUBE

STEP 1

Set Screw M3x3
C-3004-30-03

L=R

STEP 2

BH M2.5x8
C-3003-25-08

STEP 3

C-00180-033 (set)

Set Screw M3x3
C-3004-30-03

BH M2.5x18
C-3003-25-18

STEP 4

BH M3x16
C-3003-30-16

L=R

STEP 5

C-00180-220

C-00180-149

C-00180-089

L=R

STEP 6

Set Screw M3x3
C-3004-30-03

C-00180-246

C-00180-231