

(C) INDICATES CHROME PARTS

AMT® kits are molded from the finest high-impact styrene plastic. Use only paint and cement made for styrene plastic. Trim off any excess plastic before cementing parts together. When attaching CHROME parts (indicated by "C" after part names), scrape plating away where cement is to be applied. Use just enough cement to join plastic parts, and be especially careful not to smear cement on exposed surfaces.

