



	FRONT DIFF	CENTRE DIFF	REAR DIFF
TRACK USE	7500cps	15.000cps	5000cps
OFF ROAD	10.000cps	30.000cps	7500cps
FACTORY	20.000cps	50.000cps	10.000cps

Required Tools:

- 2.0 Hex Driver
- Silicone Diff Oil 
- Paper Towel
- Solvent/Brake Cleaner
- Hobby Knife or Other Sharp Tool
- Pliers

Finish Before:

- Front Diff Removal or Rear Diff Removal

Important Notice:

Do NOT use solvents on rubber gaskets or O-rings to prevent damage.

STEP 1

FH M3x10
C-3002-30-10

 
Coat all components with
diff oil prior to reassembly.

C-00180-183-2 → Thin
C-00180-183 → Thick


Fill the oil to approximately
75% capacity.

STEP 2

C-00180-179 (set)

C-00180-184

STEP 3

C-00180-179 (set)

C-00180-205

STEP 4

BB 8x16x5
C-3611-3-08-16-05

C-00180-153-3

 
Coat all components with
diff oil prior to reassembly.

C-00180-182

C-00180-098

C-00180-179 (set)

STEP 5

C-00180-179 (set)

C-00180-205

STEP 6

BB 8x16x5
C-3611-3-08-16-05

C-00180-153-3

C-00180-179 (set)

Shim 13x16x0,1
C-3301-13-16-01

 
Coat all components with
diff oil prior to reassembly.

C-00180-182

C-00180-688