
REAR DIFF REMOVAL




Required Tools:

- 2.0 Hex Driver
- 2.5 Hex Driver
- Lithium Grease (GR)


Important Notice:

Wing is not shown for clarity.

STEP 1



STEP 2



STEP 3

