




Required Tools:

- 2.0 Hex Driver
- 2.5 Hex Driver
- 5.5 Nut Driver

STEP 1

BH M3x14
C-3003-30-14

M3 Locknut
C-3101-30-6

L=R

STEP 2

BH M3x18
C-3003-30-18

C-00230-0081

M3 Locknut
C-3101-30-6

L=R

STEP 3

C-00230-0082

C-00230-0008 (set)

C-00230-0082

L=R

STEP 4

C-00230-0069

C-00230-0065 (set)

BB 5x10x4
C-3611-3-05-10-04

C-00230-0008 (set)

C-00230-0056

L=R

STEP 5

C-00230-0065 (set)

L=R