

Advantage CapacitorA Instruction Manual Ver1.0

Thank you for using our products. Please read this manual before use.

This is used with Brushless motors. This part is useful when power drops during the last half of a race.

This can help with bettering a total average lap time, therefore the whole elapsed time is reduced.

**This effect may be differ depending on the ESC used.

<How to Install>

Please solder the red wire to the battery terminal (+), black wire to the battery terminal (-).

Confirm the polarity of your ESC using this manual.

<Caution>

- * There is a different effect depending upon the type of ESC that is used.
 - * This unit has a polarity. This unit will brake when the polarity is not correct. Be sure to connect it correctly.
 - * Please install with glue to chassis or ESC. Don't install to parts that may be hot. (ex: motor, etc)
 - * Please stop using, when you feel that this unit is too hot or has a strange smell.
- We are not able to correspond to questions regarding other manufacturer's ESC. Please ask the manufacture.

Contact information for repairing goods

Requesting repair service

Please write the following items in as much detail as possible and send it with the repair goods.

- (1) Situation of the trouble.
- (2) Equipment used. (type of transmitter, receiver, servo, and esc)
- (3) Vehicle name and installing situation when being installed.
- (4) The type and the number of items that have been sent.
- (5) Return address, name, and telephone number.

KONDO KAGAKU Co., Ltd. Service department
TEL : 03-3807-7648 (service)

Hours of operation: 9:00-12:00 & 13:00-17:00 M-F except national holidays
Saturday and Sunday closed

ADDRESS : 4-17-7 Higashi-Nippori, Arakawa-ku Tokyo Japan 116-0014 Japan

Latest information can be accessed here.

>> <http://www.kopropro.co.jp>