



CUTTY SARK

TEA CLIPPER - 1869

Parts list / Listado de piezas / Liste des pièces / Teileliste



22800 - 1	22800 - 2	22800 - 3	22800 - 4	22800 - 6	22800 - 8	Piezas de Fotogrado / Photoetched Parts Pièces photodécoupées / Fotoätzteile 0.3 mm BRASS - (200 x 132 mm)
1.5 mm - PLYWOOD (450 x 300 mm)	1.5 mm - PLYWOOD (450 x 150 mm)	1.5 mm - SAPELLY (100 x 90 mm)	1.5 mm - WALNUT (400 x 90 mm)	3 mm - PLYWOOD (450 x 100 mm)	5 mm - PLYWOOD (300 x 300 mm)	
21	22	51	124 (x2)	14 (x4)	4	Número de pieza Part number Numéro de pièce Teilenummer
23	24	57	128 (x4)	17 (x4)	5	Cantidad Quantity Quantité Menge
25.A	34.A(L)	68 (x2)	141 (x2)	18 (x4)	6	77 (x2)
25.B	34.A(R)	69 (x2)	175 (x2)	19 (x4)	7	78 (x2)
27	34.B(L)	70 (x2)	176 (x2)	20 (x4)	8	79 (x1)
29(x2)	34.B(R)	131 (x2)	177 (x2)	EB1	9	105 (x2)
43 (x2)	61 (x2)	167 (x12)	178 (x2)	EB2	10	(156 + 157 + 158) (x2)
46	75 (x12)	288 (x2)	200 (x2)	EB3	11	(236 + 237) (x2)
65(x2)	169 (x2)		217	EB4	12	238.a (x2)
67(x2)	170 (x2)	22800 - 5	218 (x2)			276.A (x1)
121(x2)		2 mm - SOLID WOOD (100 x 90 mm)	219 (x2)	22800 - 7	22800 - 9	276.B (x2)
123	171	81 (x2)	222	5 mm - PLYWOOD (450 x 225 mm)	5 mm - SAPELLY (350 x 45 mm)	290.B (x2)
137(x2)	172 (x2)	82 (x2)	230 (x2)	1.A	35	(292 + 293) (x1)
138(x2)	173 (x2)	85 (x2)	231 (x4)	1.B	38	305 (x2)
139(x2)	174	86 (x2)	232 (x2)	1.C (x2)	39	(311 + 312) (x2)
213(x2)	199 (x4)	101 (x2)	233 (x2)	2	40	(321 + 276) (x1)
214	203 (x2)	102 (x2)	234 (x2)	3	41 (x2)	(325 + 326 + 327) (x1)
215	239 (x2)	154 (x2)	243 (x2)	13	42	349 (x7)
216		155	244	15 (x2)	62	362 (x1)
227		290.C (TEMP)	245 (x2)	16	271	366 (x1)
240		333 (x6)	247 (x2)			368 (x2)
241(x2)		339 (x2)	248			373 (x2)
242		356	249 (x2)			388 (x3)
246 (x2)		430 (x10)	251 (x2)			389 (x3)
			255 (x2)			390 (x4)
			256 (x2)			412 (x42)
			260 (x2)			418 (x42)
			262 (x2)			421 (x3)

