
REAR BRACE

ONE-PAGE MANUAL




Required Tools:

- 2.0 Hex Driver
- 2.5 Hex Driver
- 5.5 Nut Driver


Important Notice:

Wing is not shown for clarity.


STEP 1




STEP 2



STEP 3



STEP 4



STEP 5

