
SYNCRO4

FRONT DIFF REMOVAL

www.corally.com TEAM CORALLY MODELSPORT


ONE-PAGE MANUAL




Required Tools:

- 2.0 hex driver
- 2.5 hex driver
- 5.5 hex nutdriver
- Lithium Grease


STEP 1




STEP 2



STEP 3



STEP 4



STEP 5

